PROSPEX ランド・トレーサー LAND TRACER

クイックマニュアル

お問い合わせ先:

セイコーウオッチ「Bluetooth® 通信機能付きウオッチ (SEIKO WATCH LINK)」のご使用方法・修理・メンテ ナンスのご質問は下記の窓口までお問い合わせください。

セイコースポーツ商品サービスセンター 047-320-3004

受付日時・夏季休業・年末年始につきましては当社ホーム ページでご確認ください。

http://www.seiko-watch.co.ip/contact/

- ※電話機が非通知設定の場合は、電話番号の前に「186」 をつけておかけください。
- ※App Store は、Apple Inc. のサービスマークです。
 ※iOS は、米国およびその他の国における Cisco 社の商標または登
- 録商標です。
- ※Google Play、Android は、Google Inc. の商標です。
- ※Bluetooth®は、Bluetooth SIG. Inc.の商標または登録商標です。 セイコーウオッチ株式会社は、このロゴマークをライセンスに基 づいて使用しています。

● ペアリング

初めて使うときには、時計とスマートフォンのペアリング を行ってください。2 回目以降は Bluetooth 通信すると きにペアリングは不要です。詳しくは⇒取扱説明書 P.27

■ ペアリングの準備

- 1. スマートフォンの Bluetooth 機能を有効にします。 ※Bluetooth 機能の設定方法はスマートフォンの機種により異 なります。詳しくは、お手持ちのスマートフォンの操作説明 をご確認ください。
- 2. 専用アプリケーション「LAND TRACER」を起動します。 ペアリング時は、アプリケーションがスマートフォンの 画面に表示された状態にしてください。

■ ペアリングの開始

1. ペアリングを設定します。 ボタンFを「ピッ」と鳴るまで長押 ししてください。



2.ペアリングの完了を確認します。 時計がアプリケーションに接続する と、上段のコネクトマークがつなが ります。

アプリケーションに「時計に接続し ました」と表示され、次に「同期し ました」と表示されればペアリング の完了です。



コネクトマーク

● 表示と操作ボタン

■ 時計の各ボタン表示(英語)とガイダンスマーク で主な操作をガイドします。



★外側ボタン表示 主に時計モードで使用す る機能を表示します。

★内側ボタン表示 主にフィールドモードで使 用する機能を表示します。




★ガイダンスマーク(▶) 各モードで使用頻度の高い ボタンを「▶ | マークが教 えてくれます。

● LAND TRACER のモード

時計モード (WATCH MODE)

■ ボタンBを押すごとにモードが 順に切り替わります。



2. こよみ情報モード 詳しくは⇒取扱説明書 P.39 日の出入時刻、月の出入時刻、月齢、月の満ち欠け、 潮回りを表示

3. ストップウオッチモード 詳しくは⇒取扱説明書 P.41

4. アラームモード 詳しくは⇒取扱説明書 P.43

5. ソーラーモニターモード 詳しくは⇒取扱説明書 P.46 現在の発電レベルと電池残量を詳細表示

フィールドモード (FIELD MODE)

■ ボタンAを押すごとにモードが ボタンA 順に切り替わります。

1. ウェザーモード 詳しくは⇒取扱説明書 P.55 天気予報情報を表示

2. 高度計モード 詳しくは⇒取扱説明書 P.61

3. 気圧・温度計モード 詳しくは⇒取扱説明書 P.67

4. 方位計モード 詳しくは⇒取扱説明書 P.71

※こよみ情報モードとウェザーモードは、Bluetooth 通信に よりアプリケーションから送られた各情報を表示します。

● 専用アプリケーションのインストール

1. スマートフォンの機種、OS のタイプとバージョン を確認してください。

対応機種/ OS については、当社ウェブサイトにてご確認 ください。

(http://www.seiko-watch.co.ip/support/watchlink/)

2. 専用アプリケーション「LAND TRACER」をダウン ロードしてください。

iOS の場合: 「App Store」からダウンロードで きます。

Android の場合: 「Google Play」からダウンロード

できます。

3. 専用アプリケーション「LAND TRACER」をスマート フォンにインストールしてください。

※アプリケーションの指示にしたがって設定してくださ

※アプリケーションでは位置情報やモバイルデータ通信な どを使用します。

※アプリケーションから求められた場合は、使用を許可す る設定にしてください。

● フィールドモードの REC 機能の使いかた

移動中の高度、位置、天気などの推移を時間の経過とともに自動的に記録します。記録した情報は、 フィールドログとしてアプリケーションに保存され、確認できます。詳しくは⇒取扱説明書 P.48

■ フィールドログを取ろう


※3D (3次元) のトレースログを取るには、スマートフォンのアプリ ケーションを起動または待機状態にしておいてください。


ボタンAを押してフィールド モードのいずれかのモードを 表示します。





ボタンE (REC) を長押し します。








その後、自動でスマートフォン と接続します。

REC マークが点滅し、記録

を開始します。



※記録中、ボタンFの長押し操作により、その地点における時刻、高度、 位置、天気などの情報(ログポイント)をフィールドログに記録できます。 ※ログの計測間隔をアプリケーションで設定できます。

■ フィールドログの記録を終了する

記録終了時は、ボタン(REC)を「REC off」が表示さ れるまで長押ししてください。

■ フィールドログを確認する

以下のデータがフィールドログとして記録され、アプリ ケーションで確認することができます。

・記録開始日

· 開始高度/開始時刻

·終了高度/終了時刻 計測時間 移動距離 ·最高到達高度/到達時刻

・最低到達高度/到達時刻・タイムライン

・ログポイント ・写真(途中で撮影した写真 を登録できます。)

移動した軌跡をグラフ表示(下図:3Dログの例)すること ができます。



※フィールドログは SNS へ投稿することができます。

FAQ

質問	回答
時計のバッテリーはど れくらい持ちますか?	ソーラー充電機能付ですので、基本的に電池切れの心配はありません。 ソーラーモニターモードで電池残量 を確認し、明るい場所で充電を心掛けてください。
防水に対応しています か?	日常生活用強化防水で20気圧防水で す。空気ボンベを使用しないスキン ダイビングに使用できます。
時計だけでフィールド モードの記録ができま すか?	3 D (3 次元) のトレースログは、 アブリケーションを起動したスマート フォンを一緒に携帯し記録することが 必要です。高度グラフは、時計だけ で記録できます。
ウェザーモードで天気 予報が表示されないの ですが?	時計で天気予報を見るには、アプリケーションと同期する必要があります。アプリケーションの設定で自動同期設定しておくと、設定した時刻に更新され便利です。
スマートフォンを機種交換 しましたが、ペアリングが 必要ですか?	スマートフォンを交換した時は、最初に時計のペアリング解除(詳しくは⇒取扱説明書 P. 29)を行ってから、新しいスマートフォンと時計のペアリングを行ってください。近くに以前のスマートフォンがある場合は、混信を防ぐためBluetooth機能をOFFにしてください。

※最新の情報は、当社ウェブサイトにてご確認ください。

PROSPEX LAND TRACER

QUICK MANUAL

Contact Information:

If you have any question about the operation, repair or maintenance of your SEIKO Bluetooth® Communication Watch (SEIKO WATCH LINK), please contact the following:

SEIKO Sports Product Service Center

Tel: 047-320-3004

For business hours, and summer and New Year's holidays, please visit our website:

http://www.seiko-watch.co.jp/contact/

- *If your phone is set to "number withheld," add "186" to the above phone number.
- *App Store is a service mark of Apple Inc.
- *iOS is a trademark or registered trademark of Cisco in the U. S. and other countries.
- Google Play and Android is a trademark of Google Inc.
- *Bluetooth® is a trademark or a registered trademark of Bluetooth SIG, Inc.

Seiko Watch Corporation uses this logo under license.

PAIRING

Before using the watch with a smartphone for the first time, be sure to perform pairing procedure. Pairing is no longer required for Bluetooth communication thereafter. See p.121 ff. of the Instructions.

Before Performing Pairing

- 1. Enable the Bluetooth function on the smartphone.
 - *The method of enabling the Bluetooth function differs depending on the model of the smartphone. For details, please refer to the instruction manual for your smartphone.
- 2. Start up the dedicated application "LAND TRACER." While performing pairing, make sure that the application screen is displayed on the smartphone.

■ To Start Pairing

- 1. Start the pairing procedure. Press and hold Button (F) until a confirmation beep sounds.
- 2. Check that the pairing has succeeded. When the watch is connected to the application, the graphics in the top row of the display indicates that the connection is established.
- When "Connection has been established with Watch" is displayed on the application screen, and then followed by "Synchronization succeeded." pairing is achieved.



Button (F).

Graphics for connection



MARKINGS AND BUTTONS

The markings on the case and the guidance marks shown on the display support you for easy button operation.



★Markings on case side: Indicate the functions mainly used in Watch modes.

★Markings on case front: Indicate the functions mainly used in Field modes.



★Guidance mark ():

"▶" marks are shown on the display to point at the buttons used frequently in the mode in use.

● MODES OF LAND TRACER

WATCH MODES

 With each press of Button B, the mode changes in the following order:



- 2. Almanac Information mode See p.133 ff. of the Instructions. Sunrise/sunset times, moonrise/moonset times, moon's age, moon phase and tide are displayed.
- 3. Stopwatch mode

See p.135 ff. of the Instructions.

4. Alarm mode

See p.137 ff. of the Instructions.

Button (B)

5. Solar Monitor mode See p.140 ff. of the Instructions. Current power generation level and power reserve are displayed.

FIELD MODES

With each press of Button (A), the mode changes in the following order:

1. Weather mode See p.149 ff. of the Instructions. Weather forecast information is displayed.

2. Altimeter mode See p.155 ff. of the Instructions.

3. Barometer/Thermometer mode See p.161 ff. of the Instructions.

4. Compass mode See p.165 ff. of the Instructions.

% Almanac Information and Weather modes display the respective information transmitted from the application via Bluetooth communication.

• INSTALLATION OF APPLICATION

1. Check the model number of your smartphone and the type and version of the OS running on it.

For the models and OSs supported by the LAND TRACER watch, visit our website: (http://www.seiko-watch.co.jp/support/watchlink/)

2. Download the application "LAND TRACER" for exclusive use with the LAND TRACER watch.

For iOS: Download from "App Store." Download from "Google Play." For Android:

- 3. Install the dedicated application "LAND TRACER" on your smartphone.
 - *Configure the application according to the instructions given in it.
 - *The LAND TRACER application uses position information, and performs mobile data communication.
 - If the application requests permission to use them, set the smartphone so that such permission is granted to the application.

HOW TO USE FIELD MODE REC FUNCTION

The changes in the altitude, location, weather, and other data obtained during a trip can be recorded automatically in the application as a field log for later viewing. See p. 142 ff. of the Instructions.

■ To Record a Field Log

*To record a trace log in a 3D graph format, keep the application running or on standby on the smartphone.

Press Button (A) to show any of the Field modes.

Press and hold Button (E)

"HOLD" appears. Press and

hold Button (E) further until a

The watch is connected with

the smartphone automatically.

Flashing "REC" appears, and

recording of a field log is

confirmation beep sounds.

(REC).

started.



Cional

Ex.: Weather mode Press and hold









*While the field log is recorded, the time, altitude, location, weather and other data of a given location can be recorded as a log point data with each continuous press of Button (F). *The interval for measuring data can be set in the application.

To End Recording of a Field Log

To end recording, press and hold Button (E) (REC) until "REC off" is displayed.

To View a Field Log Recorded

The following data is recorded as a field log, and can be viewed on the application.

- · Date of starting recording · Starting altitude/time
- Ending altitude/time
 Measurement duration
- · Highest altitude reached/arrival time
- · Lowest altitude reached/arrival time Time line · Distance traveled · Log point
- · Photographs (Photographs taken during recording can be registered in the field log.)

The entire route traveled during a trip can be traced on a map in a graph format (example below: log in a 3D graph format).



*The recorded field logs can be posted on SNS.

FAQs

Question	Answer
How long will the battery last?	The watch has a solar charger, and the power reserve will not be depleted during normal use. Use Solar Monitor mode to check the level of power reserve, and charge the watch under bright light.
Is the watch water resistant?	The watch is 20 bar water resistant. It is suitable for skin diving without using heavy breathing apparatus.
Is it possible to record field logs with the watch alone?	To record 3D trace logs, it is necessary to carry with the watch a smartphone on which the dedicated application is running. The altitude graph can be recorded by using the watch alone.
How can I display the weather forecast information in Weather mode?	To view the weather forecast information on the watch, it needs to be synchronized with the application. By enabling the automatic synchronization function on the application, the weather forecast information is updated at a designated time.
I bought a new smartphone. Is it necessary to perform pairing?	To use a new smartphone with the watch, cancel the previous pairing first (see p.123 of the Instructions), and then re-establish pairing between the watch and the new smartphone. If the smartphone used previously is placed near the new one, disable the Bluetooth function of the previous one to prevent interference.

*For the latest information on the watch, visit our website